

# GAZELLE<sup>®</sup>

## **G9622** Manual Hydraulic Crimping Tool (6-400mm<sup>2</sup>) User Manual



---

# Contents

<b>1. Introduction</b> .....	<b>1</b>
<b>2. Labels</b> .....	<b>1</b>
<b>3. Warranty</b> .....	<b>1</b>
<b>4. Description of the hydraulic crimping unit</b> .....	<b>1</b>
<b>5. Remarks in respect of the determined use</b> .....	<b>2</b>
5.1 Operation.....	2
5.2 Explanation of the application range.....	3
5.3 Mounting instructions.....	4
5.4 Service and maintenance instruction .....	4
5.5 Storage and transport of the crimping tool .....	4
5.6 Reference as to which spare parts can be exchanged by the customer.....	5
<b>6. Troubleshooting</b> .....	<b>5</b>
<b>7. Putting out of operation/wasted disposal</b> .....	<b>5</b>
<b>8. Technical Data</b> .....	<b>5</b>

## 1. Introduction

- Use this tool exclusively for its determined use.
- Mounting and assembly of connecting material with the help of this tool must only be performed by specially trained personnel. The minimum age is 16 years.
- This instruction manual must be carried along during the entire life span of that tool.
- The operator has
  - to guaranty the availability of the instruction manual for the user and
  - to make sure, that the user has read and understood the instruction manual.

## 2. Labels

On the labels fixed on the unit you'll find the type specification name of the manufacturer and/or the company logo. On the cylinder you find the serial number.

## 3. Warranty

If correct operation is guaranteed and regular service is provided our warranty is 1 year from the time of delivery.

## 4. Description of the hydraulic crimping unit

The hand-hydraulic crimping unit type G9622 is a hand-held tool and consists of the following components:

POS.- NO.	Description	Function
1	Dies	Crimping
2	Crimping head	120KN C-shape head for wide crimping dies
3	Pump handle	To operate the pump

4	Retract lever	To activate the pressure relief valve and to return the dies in to starting position
5	Guiding handle	To guide and position the tool
6	Turn screw	To activate the transportation lock

## 5. Remarks in respect of the determined use

### 5.1 Operation

First you have to select the right dies for the intended application.

#### **Attention:**



#### ***Don't use the tool without dies***

1. Afterwards the dies will be inserted laterally into the crimping head until the die lock engages and locks the die securely. Then the connecting material must be positioned in the crimping. In order to start the crimping procedure, the turn screw must be turned 180° while the pump lever is pushed towards the handle.

2. A crimping process is initiated by activating the pump lever. It is defined by the closing motion of the dies. The connecting material is positioned in the stationary half of the crimping dies and the moving part is approaching the compression point.

3. The tool is equipped with a double piston pump which is characterized by a fast approach of the die towards the connecting material and a slow working speed with forces to crimp the connector. In the low-pressure mode, the fast approach is realized while opening the pump lever and the slow by closing it. In the high-pressure mode, the compression is realized by closing the pump lever only.

4. A crimping cycle is terminated when the dies contact each other and when the maximum crimping force is reached. This is indicated by a significant decrease of the handle force.

5. After the crimping is completed, if the rated pressure value is not reached, the return lever can be used to manually return the piston to the starting position to achieve pressure relief and return oil; if the rated pressure value has been reached, the tool will automatically release the pressure and the piston will automatically retract. Afterwards a new crimping cycle can be initiated or the crimping process can be terminated and the connecting material removed

out of the crimping head.

6. Before storing the tool the turn screw has to be turned 180° and the handles must be closed until the lock is activated.

## 5.2 Explanation of the application range

Our hydraulic crimping tool has a large number of various dies available to crimping primarily copper and aluminum but other connecting materials.

Table 2

Crimping range mm <sup>2</sup>	Crimping dies	Marking outside	Profile	Surface of the dies	Width
6-300	TCL and C. Standard Version	CU, „QS“	„QS“	Chrome plated (yellow)	5mm
6-240	TCL and C. DIN46235/DIN4626 7	CU, „QS“ DIN46235	code#	Chrome plated (yellow)	5mm
10-240	Aluminum CL and C.	AL, „QS“	code #	Blue zinc	7m m
25-185	aluminum C. High-strength aluminum wire	AL, „QS“	code #	Blue zinc	7m m
25/4-120-20	Full tension C.	AL, „QS“	code #	Blue zinc	7m m
		ST, „QS“	code #	black	5mm
10-240sm 35-300se	Pre-rounding dies	RU; QS, sm; QS, sm;	-	Chrome plated (yellow)	-
10-70	Terminals DIN46234/46230	CU, „QS“ DIN46234	„QS“	Chrome plated (yellow)	-
10-70	Insulated terminals	ISQ, QS	„QS“	Chrome plated	-
10-70	Tub.CL.for fine-str. conductors	F, QS	„QS“	Chrome plated	-
4-50	C clamps	C, QS	-	Chrome plated	5mm
10-150	Pre-insulated tub.CLT and connectors	IS, QS	„QS“	Chrome plated	-

2×50-2×70	Double CL	DP, QS	„QS“	Chrome plated	5mm
10-50	Ni-Cl and connectors	NI, QS	-	Blue zinc	5mm
10-70	Oval connectors	CU or AL QS	code #	Chrome plated	5mm
10-185	WF DIN 46228	AE, QS	-	Chrome plated	-
2×4-2×16	Double WF	AE,2×QS	-	Chrome plated	-

**Attention**



***Do only crimp copper and AL conducting material or special connecting material mentioned in table 2. Do not crimp on live cable or conductors.***

**5.3 Mounting instructions**

If other application that exceeds those mentioned in table 2 must be performed with this tool it is necessary to contact the manufacturer.

Despite the same numbers the compression width for copper and aluminum cable lugs and connectors is different. Besides the marking of the dies the plating is different too.

**Attention:**



***Even if the code number is identical only those dies should be used which are suitable for the material.***

**5.4 Service and maintenance instruction**

The hydraulic crimping unit has to be cleaned and dried after use. The unit is basically maintenance-free, only the bolt joints have to be oiled regularly.

**5.5 Storage and transport of the crimping tool**

In order to protect the tool against damages it has to be cleaned carefully after every use and be put into the transportation case which has to be close safely.

## 5.6 Reference as to which spare parts can be exchanged by the customer

Within the determined use of the tool only the dies are permitted to be changed by customer.

## 6. Troubleshooting

1. The dies came to a standstill during the crimping process respectively the crimping tool doesn't reach the final operation pressure.

=> Actuate the pump lever and simultaneously push the retract lever.

2. The tool loss oil

=> Return the tool to the manufacturer. Do not open the tool and damage the seal of the tool.

## 7. Putting out of operation/wasted disposal

The disposal of the various components of the tool has to be treated separately. Doing that the first step is to dispose of the oil at special delivery points.

### **Attention**



**Hydraulic oils represent a danger for the ground-water.**

**Uncontrolled draining of or improper disposal is under penalty (environmental liability law).**

## 8. Technical Data

Crimping head can be turned 360° in a pressure free state.

Weight of the crimping tool:	700 bar
Crimping force:	Max 400mm <sup>2</sup>
Stroke:	Standard dies:
Rated pressure:	Dimension:
Crimping capacity:	
6.1KG	Cu6-400mm <sup>2</sup>
120KN	56*17*7cm
42 mm	



We shall in no event be liable for death, injuries to persons or property from the improper use and lack of maintenance of our product. Any doubt of safety operation and precaution, please contact with our distributor.



Please properly dispose of all packing materials and removed parts.



INNOVATION  
PERFORMANCE  
SAFETY  
CONFIDENCE  
GAZELLE

**GAZELLE**

[sales@gazelleindustrial.com](mailto:sales@gazelleindustrial.com) | [www.gazelleindustrial.com](http://www.gazelleindustrial.com)